






Electric Landscaping Equipment Grants for Businesses



Eligible Equipment List



Brand	Type	Image	Model Number	Required Accessories Each piece of equipment needs to be sold with the following accessories to ensure adequate operating times*.
Stihl	Blower		BGA 86	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x3 Battery (AP300S or AP500S) x3 Charger (AL300 or AL301 or AL500)
Stihl	Backpack Blower		BGA 200	x1 Backpack battery (AR2000L or AR3000L) x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500)
Stihl	Backpack Blower		BGA 300	x1 Backpack battery (AR2000L or AR3000L) x1 Charger (AL300 or AL301 or AL500) Unit with AR2000L (Runtime = Longer Weight = Heavier) Unit with AR3000L (Runtime = Shorter Weight = Lighter) <i>Note: Please make sure to review and test the weights when making you purchasing decision.</i>
Stihl	Combination Unit (the following attachments can be included with the unit: Grass Blade, Trimmer, and/or Edger)		KMA 135R	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x2 Battery (AP300S or AP500S) x2 Charger (AL300 or AL301 or AL500)
Stihl	String Trimmer		FSA 135R	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x2 Battery (AP300S or AP500S) x2 Charger (AL300 or AL301 or AL500)



*If customer is buying or owns multiple pieces of equipment that use the same battery then they can opt to purchase less than the recommended batteries, chargers and/or other accessories at their discretion.

This list changes as the pilot program develops based on retailer or customer demand Apply to the program or check for the most updated list: <https://pacepartners.com/small-business/>

Electric Landscaping Equipment Grants for Businesses



Eligible Equipment List



Brand	Type	Image	Model Number	Required Accessories Each piece of equipment needs to be sold with the following accessories to ensure adequate operating times*.
Stihl	Pole Pruner		HTA 135	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x2 Battery (AP300S or AP500S) x2 Charger (AL300 or AL301 or AL500)
Stihl	Hedge Trimmer		HLA 86 or HLA 135	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x2 Battery (AP300S or AP500S) x2 Charger (AL300 or AL301 or AL500)
Stihl	Mower 21"		RMA 510V	x4 Battery (AP300S) x4 Charger (AL300) -OR- x4 Battery (AP500S) x4 Charger (AL500)
Stihl	Extra Backpack Battery		AR 2000L or AR 3000L	Optional Accessories: x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500)
Stihl	Extra Battery		AP 300S or AP 500S	x1 Charger (AL300 or AL301 or AL500)
Stihl	Multi-Charger		AL 301-4	



*If customer is buying or owns multiple pieces of equipment that use the same battery then they can opt to purchase less than the recommended batteries, chargers and/or other accessories at their discretion.






This list changes as the pilot program develops based on retailer or customer demand Apply to the program or check for the most updated list: <https://pacepartners.com/small-business/>

Electric Landscaping Equipment Grants for Businesses



Eligible Equipment List



Brand	Type	Image	Model Number	Required Accessories Each piece of equipment needs to be sold with the following accessories to ensure adequate operating times*.
Husqvarna	Backpack Blower		340iBT	X4 Batteries (BLI200 or BLI200X or BLI300) X4 Charger (QC250)
Husqvarna	Backpack Blower		550iBXT	x1 Backpack battery (BLI550X or BLI950X) x1 Charger (QC330 or QC500) Unit with BLI950X (Runtime = Longer Weight = Heavier) Unit with BLI550X (Runtime = Shorter Weight = Lighter) <i>Note: Please make sure to review and test the weights when making you purchasing decision.</i>
Husqvarna	Hedge Trimmer		520iHE3 or 520iHT4 or 520iHD60 or 522iHD60	x1 Backpack battery (BLI550X or BLI950X) x1 Battery Adaptor Cable x1 Charger (QC500) -OR- x2 Batteries (BLI200 or BLI200X or BLI300) x2 Charger (QC330 or QC500)
Husqvarna	Combination Unit (the following attachments can be included with the unit: Grass Blade, Trimmer, and/or Edger)		525iLK	x1 Backpack battery (BLI550X or BLI950X) x1 Battery Adaptor Cable x1 Charger (QC500) -OR- x2 Batteries (BLI200 or BLI200X or BLI300) x2 Charger (QC330 or QC500)
Husqvarna	String Trimmer		520iLX or 525iLST	x1 Backpack battery (BLI550X or BLI950X) x1 Battery Adaptor Cable x1 Charger (QC500) -OR- x2 Batteries (BLI200 or BLI200X or BLI300) x2 Charger (QC330 or QC500)



*If customer is buying or owns multiple pieces of equipment that use the same battery then they can opt to purchase less than the recommended batteries, chargers and/or other accessories at their discretion.







This list changes as the pilot program develops based on retailer or customer demand Apply to the program or check for the most updated list: <https://pacepartners.com/small-business/>

Electric Landscaping Equipment Grants for Businesses



Eligible Equipment List



Brand	Type	Image	Model Number	Required Accessories <small>Each piece of equipment needs to be sold with the following accessories to ensure adequate operating times*.</small>
Husqvarna	Pole Saw		525iDESP MADSAW	x1 Backpack battery (BLi550X or BLi950X) x1 Battery Adaptor Cable x1 Charger (QC500) -OR- x2 Batteries (BLI200 or BLI200X or BLi300) x2 Charger (QC330 or QC500)
Husqvarna	Edger		525iES or 525IECS	x1 Backpack battery (BLi550X or BLi950X) x1 Battery Adaptor Cable x1 Charger (QC500) -OR- x2 Batteries (BLI200 or BLI200X or BLi300) x2 Charger (QC330 or QC500)
Husqvarna	Mower 20"		W520i	X2 Backpack battery (BLi550X or BLi950X) x1 Battery Adaptor Cable x2 Charger (QC500) -OR- X4 Batteries (BLI200 or BLI200X or BLi300) X4 Charger (QC330 or QC500)
Husqvarna	Extra Backpack Battery		BLi550X or BLi950X	Optional Accessories: x1 Battery Adaptor Cable x1 Carrying system x1 Charger (QC500)
Husqvarna	Extra Battery		BLI200 or BLI200X or BLi300	x1 Charger (QC330 or QC500)
Husqvarna	Charging Rail (For overnight charging)		970621903	



**If customer is buying or owns multiple pieces of equipment that use the same battery then they can opt to purchase less than the recommended batteries, chargers and/or other accessories at their discretion.*

This list changes as the pilot program develops based on retailer or customer demand Apply to the program or check for the most updated list: <https://pacepartners.com/small-business/>

Electric Landscaping Equipment Grants for Businesses



Eligible Equipment List



Brand	Type	Image	Model Number	Required Accessories <small>Each piece of equipment needs to be sold with the following accessories to ensure adequate operating times*</small>
Makita	Blower Kit (1x Battery and charger included)		GBU01M1	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	Backpack Blower		CBU02Z	1x Backpack battery (PDC1200A01)
Makita	Hedge Trimmer		GHU02M1 or EN401MP or GHU05M1	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	Combination Unit (the following attachments can be included with the unit: Grass Blade, Trimmer, Pole Saw and/or Edger)		GUX01Z	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	String Trimmer		GRU04M1	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	Mower 21"		CML01Z	x1 Backpack battery (PDC1200A01) x 21" mower blade (191D52-7)



**If customer is buying or owns multiple pieces of equipment that use the same battery then they can opt to purchase less than the recommended batteries, chargers and/or other accessories at their discretion.*



This list changes as the pilot program develops based on retailer or customer demand Apply to the program or check for the most updated list: <https://pacepartners.com/small-business/>

Electric Landscaping Equipment Grants for Businesses



Eligible Equipment List



Brand	Type	Image	Model Number	Required Accessories Each piece of equipment needs to be sold with the following accessories to ensure adequate operating times*.
Makita	Extra Backpack Battery		PDC1200A01	
Makita	Extra Battery		BL4040	



**If customer is buying or owns multiple pieces of equipment that use the same battery then they can opt to purchase less than the recommended batteries, chargers and/or other accessories at their discretion.*

This list changes as the pilot program develops based on retailer or customer demand Apply to the program or check for the most updated list: <https://pacepartners.com/small-business/>