



Brand	Туре	Image	Model Number	Recommended Accessories We recommended that each piece of equipment should be sold with the following accessories to ensure adequate operating times
Stihl	Blower		BGA 86	x1 Backpack battery (<u>AR2000L</u> or <u>AR3000L</u>) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (<u>AL300</u> or <u>AL500</u>) -OR- x3 Battery (<u>AP300S</u> or <u>AP500S</u>)
Stihl	Backpack Blower		BGA 200	x3 Charger (AL300 or AL301 or AL500) x1 Backpack battery (AR2000L or AR3000L) x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500)
Stihl	Backpack Blower		BGA 300	x1 Backpack battery (AR2000L or AR3000L) x1 Charger (AL300 or AL301 or AL500) Unit with AR2000L (Runtime = Longer Weight = Heavier) Unit with AR3000L (Runtime = Shorter Weight = Lighter) Note: Please make sure to review and test the weights when making you purchasing decision.
Stihl	Combination Unit (the following attachments can be included with the unit: Grass Blade, Trimmer, and/or Edger)		<u>KMA</u> 135R	x1 Backpack battery (<u>AR2000L</u> or <u>AR3000L</u>) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (<u>AL300</u> or <u>AL500</u>) -OR- x2 Battery (<u>AP300S</u> or <u>AP500S</u>) x2 Charger (<u>AL300</u> or <u>AL301</u> or <u>AL500</u>)
Stihl	String Trimmer		FSA 135R	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x2 Battery (AP300S or AP500S) x2 Charger (AL300 or AL301 or AL500)









Brand	Туре	Image	Model Number	Recommended Accessories We recommended that each piece of equipment should be sold with the following accessories to ensure adequate operating times
Stihl	Pole Pruner		HTA 135	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x2 Battery (AP300S or AP500S) x2 Charger (AL300 or AL301 or AL500)
Stihl	Hedge Trimmer		HLA 86 or HLA 135	x1 Backpack battery (AR2000L or AR3000L) x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500) -OR- x2 Battery (AP300S or AP500S) x2 Charger (AL300 or AL301 or AL500)
Stihl	Mower 21"		RMA 510V	x4 Battery (AP300S) x4 Charger (AL300) -OR- x4 Battery (AP500S) x4 Charger (AL500)
Stihl	Extra Backpack Battery	ero	AR 2000L or AR 3000L	Optional Accessories: x1 AP Adapter x1 Connecting cable x1 Carrying system x1 Charger (AL300 or AL500)
Stihl	Extra Battery	\$ 10ML	AP 300S or AP 500S	x1 Charger (<u>AL300</u> or <u>AL301</u> or <u>AL500</u>)
Stihl	Multi- Charger		AL 301-4	





Accessory Recommendations for Common Equipment Types



尚Husqvarna^{*}

Brand	Туре	Image	Model Number	Recommended Accessories We recommended that each piece of equipment should be sold with the following accessories to ensure adequate operating times
Husqvarna	Backpack Blower		<u>340iBT</u>	X4 Batteries (BLI200 or BLI200X or BLi300) X4 Charger (QC250)
Husqvarna	Backpack Blower		550iBXT	x1 Backpack battery (BLi550X or BLi950X) x1 Charger (QC330 or QC500) Unit with BLi950X (Runtime = Longer Weight = Heavier) Unit with BLi550X (Runtime = Shorter Weight = Lighter) Note: Please make sure to review and test the weights when making you purchasing decision.
Husqvarna	Hedge Trimmer	Service Services	520iHE3 or 520iHT4 or 520iHD60 or 522iHD60	x1 Backpack battery (<u>BLi550X</u> or <u>BLi950X</u>) x1 Battery Adaptor Cable x1 Charger (<u>QC500</u>) -OR- x2 Batteries (<u>BLI200</u> or <u>BLI200X</u> or <u>BLi300</u>) x2 Charger (<u>QC330</u> or <u>QC500</u>)
Husqvarna	Combination Unit (the following attachments can be included with the unit: Grass Blade, Trimmer, and/or Edger)	& G	<u>525iLK</u>	x1 Backpack battery (<u>BLi550X</u> or <u>BLi950X</u>) x1 Battery Adaptor Cable x1 Charger (<u>QC500</u>) -OR- x2 Batteries (<u>BLI200</u> or <u>BLI200X</u> or <u>BLi300</u>) x2 Charger (<u>QC330</u> or <u>QC500</u>)
Husqvarna	String Trimmer	S R	520iLX or 525iLST	x1 Backpack battery (<u>BLi550X</u> or <u>BLi950X</u>) x1 Battery Adaptor Cable x1 Charger (<u>QC500</u>) -OR- x2 Batteries (<u>BLI200</u> or <u>BLI200X</u> or <u>BLi300</u>) x2 Charger (<u>QC330</u> or <u>QC500</u>)





Accessory Recommendations for Common Equipment Types



尚Husqvarna^{*}

Brand	Туре	Image	Model	Recommended Accessories We recommended that each piece of equipment should be sold with
	,,	J	Number	the following accessories to ensure adequate operating times
Husqvarna	Pole	1	525iDESP	x1 Backpack battery (<u>BLi550X</u> or <u>BLi950X</u>)
	Saw	8	MADSAW	x1 Battery Adaptor Cable
				x1 Charger (QC500)
				-OR-
				x2 Batteries (<u>BLI200</u> or <u>BLI200X</u> or <u>BLi300</u>)
				x2 Charger (<u>QC330</u> or <u>QC500</u>)
Husqvarna	Edger		<u>525iES</u> or	x1 Backpack battery (<u>BLi550X</u> or <u>BLi950X</u>)
		· ·	<u>525iECS</u>	x1 Battery Adaptor Cable
				x1 Charger (QC500)
				-OR-
				x2 Batteries (<u>BLI200</u> or <u>BLI200X</u> or <u>BLi300</u>)
				x2 Charger (<u>QC330</u> or <u>QC500</u>)
Husqvarna	Mower 20"	A CONTRACTOR OF THE PARTY OF TH	W520i	X2 Backpack battery (<u>BLi550X</u> or <u>BLi950X</u>)
				x1 Battery Adaptor Cable
				x2 Charger (QC500)
				-OR-
				X4 Batteries (<u>BLI200</u> or <u>BLI200X</u> or <u>BLi300</u>)
				X4 Charger (<u>QC330</u> or <u>QC500</u>)
Husqvarna	Extra		BLi550X or	Optional Accessories:
	Backpack		BLi950X	x1 Battery Adaptor Cable
	Battery			x1 Carrying system
				x1 Charger (QC500)
Husqvarna	Extra		BLI200	x1 Charger (QC330 or QC500)
	Battery		or	<u> </u>
	•		BLI200X	
			or	
			BLi300	
Husqvarna	Charging		97062190	
	Rail		<u>3</u>	
	(For overnight	•		
	charging)			









Brand	Туре	Image	Model Number	Recommended Accessories We recommended that each piece of equipment should be sold with the following accessories to ensure adequate operating times
Makita	Blower Kit (1x Battery and charger included)		GBU01M1	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	Backpack Blower		<u>CBU02Z</u>	1x Backpack battery (PDC1200A01)
Makita	Hedge Trimmer		GHU02M1 or EN401MP or GHU05M1	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	Combination Unit (the following attachments can be included with the unit: Grass Blade, Trimmer, Pole Saw and/or Edger)		<u>GUX01Z</u>	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	String Trimmer	ST. ST.	GRU04M1	x1 Backpack battery (PDC1200A01) x1 Adapter (191N62-4) -OR- x2 Batteries (BL4040) x2 Charger (DC40RA or DC40RA)
Makita	Mower 21"		CML01Z	x1 Backpack battery (PDC1200A01) x 21" mower blade (191D52-7)









Brand	Туре	Image	Model Number	Recommended Accessories We recommended that each piece of equipment should be sold with the following accessories to ensure adequate operating times
Makita	Extra Backpack Battery		PDC1200A 01	
Makita	Extra Battery		BL4040	



